


# TIPS for "String Adjusters"

1. Write students names & class # on the side of their yo-yos.
2. Adjust the string length to each student's waist height, and make a finger loop.



**A. ADJUST THE STRING.** The perfect string length is from the floor to 3" above your waist.



**B. MAKE A SOLID LOOP.** Fold string over at the top. Tie it around itself to form a loop that is no larger than a nickel.




Cut off the extra string.

**C. MAKE A SLIP LOOP.**



**D. PROPER STRING PLACEMENT.**




3. This is the difference between "easy play" and "sleeper" yo-yos.

**HITCHED (easiest)**




**UNHITCHED (sleeper)**




4. **To avoid string breakage:** When removing tangled string or knots from around the yo-yo axle, twist the yo-yo body apart first. Take the string off the axle before twisting the two halves back together. Then put the string back on.

5. **To wind the string for a "sleeper" yo-yo:**

- A. Make the first wrap over one finger.
- B. Continue to wrap string around the axle until finished.
- C. The finger loop will disappear when you throw the yo-yo down for a "sleeper"



"Cut away" view.  
Do not take yoyo apart to wind string.



6. **To ensure proper use of the Boomerang™:** The yo-yo string must ALWAYS be hitched for easy play and for auto-return sleepers.